

L1070 ONWARDS

Moody 336 Chain Locker - Watertight Bulkhead / No Seacock.

1. Remove all loose gear, upholstery etc.
2. Mask up all areas.
3. Remove 6" Inspection cover.
4. Glass over drain holes (8oz C.S.M.) (key up topcoat area). well first).
5. Ensure good bond alround as this must be water tight. Re-topcoat if needed.
6. Fit drain into base of locker on sealant.
7. Connect drain through non-return valve to seacock. Fit seacock port side aft end 2nd bunk trap on the painted waterline). Ensure arrow on non-return points toward seacock.
8. Clip pipework up level.
9. Fit 6" inspection panel.
10. Clean out all areas.
11. Refit side lining panels.
12. Remove shell vent covers, fill holes with C.S.M. and resin paste and then re-gel and make good.

1077 onwards  
None need doing